

User Manual

Product Name: (V226)Navigation s creen

Applicable models: Toyota Alphard/Vellfire

Catalog

1 、Product Display	
.....	02
2 、Basic Operations	
.....	03
3 、Functional Application	
Main interface/air conditioning interface	04/05
Pull down the shortcut bar	05
WIFI connection	06
4G network	07
Bluetooth connection	07
set up	08
DSP Settings	09
music	09
video	10
Voice control	11
4 、Troubleshooting	
.....	12

Product Display



Basic Operations

System startup and shutdown

After turning on the ACC power supply on the vehicle, the device will automatically start up, display the power-on LOGO and the power-on animation, and then enter the system main interface. After turning off the ACC power supply on the vehicle, the device will automatically shut down.

Use of touch screen

You can use your fingers to directly operate icons, buttons, etc. on the touch screen.

Tap/hold functionality

You can tap an app icon or option on the display. For example, tapping the CCTV Video icon on the Home screen opens the Video app. Tap and hold an icon or item until the system performs the corresponding action. For example, tap and hold an app icon on the Home screen to move or delete it.

Slide function

Use your finger to slide the touch screen left and right or up and down. For example, when viewing a music playlist, slide up and down to view the playing files.

Zoom function

When you are viewing a webpage, you can use two fingers to touch and hold the screen, spread them apart to zoom in, and pinch them together to zoom out.

Program Switching


Music, video, TikTok, CCTV Video, and iQiyi cannot run at the same time

Functional Application

Main interface/air conditioning interface

On the main interface, you can click the corresponding icon to enter the corresponding function; On the main screen, tap Apps to enter the app icon screen. The app icon screen can be swiped left and right, and you can tap and hold an app icon to uninstall it. From this screen, tap an app icon to enter its corresponding app interface. The air conditioning interface is below the display; you can touch the corresponding icon to control the air conditioning.






Pull-down shortcut bar

Slide the screen from top to bottom on any interface, and a shortcut icon will appear. You can directly click on it to operate each function button.




WIFI连接

Pull down the shortcut bar and long press WIFI to jump to the WiFi interface, or click Settings on the main interface, enter the interface through the Settings icon, click Wireless Network, click the switch to turn on (on by default), search for wireless networks, find the WIFI name you want to connect to, click to enter, a password bar will pop up, enter the password to connect to the network, and after a successful connection, the WIFI icon will be displayed in the upper right corner of the interface.




4G network


When there is no WIFI, you can use the mobile 5G network (make sure the machine is equipped with a SIM card). There will be a signal in the upper right corner of the screen, which means that the 5G network is normal and you can browse the web normally



Bluetooth connection


Swipe down the screen to find the Bluetooth icon and long press Bluetooth to enter the Bluetooth interface, or click Settings-Bluetooth to enter the Bluetooth interface, turn on the switch (on by default), slide down to the bottom, click Search device, select the device to connect, and after the connection is successful, the Bluetooth indicator will be displayed in the upper right corner of the screen.





Set up

On the main interface, click the Settings icon to enter the car settings interface, where you can make settings for Bluetooth, general, sound, reverse, factory, etc, and view basic information such as the system version.




DSP Settings

Click the MIXER icon in the main APP application to enter the DSP audio adjustment interface and select different sound quality, scene mode, etc. according to personal preferences.



Music

The music player supports multiple audio formats: MP3/WMA/FLAG/WAV, etc. The playback mode is full loop/random/single loop. Favorites list function




Video

Click on the video in the main interface to enter the video playlist interface (video files must be stored locally or in USB memory)



Voice control

On the main interface, click the small portrait icon and say the application interface you want to open (for example, "open navigation"). The system will automatically open the navigation after receiving the command (network support is required), freeing you from manual operation.



Troubleshooting

Troubleshooting

Note: If you encounter the following problems during use, the following countermeasures will help you quickly resolve the problem. If the problem persists, please consult a professional or go to the sales office. Do not disassemble this device without permission to avoid serious consequences!

Phenomenon	reason	Countermeasures
Unable to boot	① The car's ACC is not activated. ② The power cord is not plugged in	① Turn on ACC ② Plug in the power cord
Unable to connect to the network	① Weak Wi-Fi signal ② The network switch is not turned on	① Move to an area with strong signal ② Turn on the switch in settings
Touch screen does not respond to touch INT	The system is processing some transactions	On the main interface, press and hold the screen with five fingers for about 1 second. The calibration interface will appear. Click the four corner calibration points '+' to recalibrate.